

WATERING MADE EASY SPRINKLER STATION LAYOUT GUIDE

Page 1 of 2.

USE THIS 2 PAGE GUIDE TO HELP DETERMINE WHERE TO LOCATE YOUR SPRINKLER STATION(S)

Use the twine included with this kit to help decide where to place the sprinklers.

PAGE 1 - SHOWS INFORMATION ABOUT THE SPRINKLER STATIONS

PAGE 2 - LAYOUT TIPS AND DIAGRAMS OF TYPICAL LAYOUTS



1-877-280-4485

WateringMadeEasy.com


FOR CUSTOMER SERVICE, PLEASE CALL 1-877-280-4485 OR EMAIL
HELP@WATERINGMADEEASY.COM

THE ORIGINAL SPRINKLER STATION:

Comes with a 30 foot long piece of twine.

Sprays 35 foot radius.

Adjustable from 15-360 degrees**.




THE SPRINKLER STATION JR.:

Comes with a 15 foot long piece of twine.

Mists a 15 foot radius.

Adjustable from 15-360 degrees**.



****MAX 340 DEGREE ANGLE RECOMMENDED TO AVOID GETTING SPRAYED WHEN TURNING ON AND OFF THE SPRINKLER AS WELL AS TO AVOID INTERFERENCE FROM THE HOSE.**

THE SPRINKLER STATION SQUARED:

Comes with a 15 foot long piece of twine.

Adjusts to mist a 9 x 18 foot rectangle, a 4 x 15 rectangle or a 4 x 30 foot rectangle.



WATERING MADE EASY SPRINKLER STATION LAYOUT GUIDE

Page 2 of 2.

1. PLAN WHERE TO PLACE THE SPRINKLER STATION

Use the twine included with this kit to help you determine where to locate the sprinkler(s).

- Have a friend hold one end of the twine where you think a sprinkler should be placed.
- Hold the other end of the twine and walk so the twine is tight. Where the twine covers should give you a general idea of the coverage of the sprinkler.

2. PLAN THE DIRECTION AND PATTERN OF SPRAY

- Plan to spray away from the hose connection.
- Original Sprinkler Station:**
Plan how far around in each direction you would like the sprinkler to spray before reversing direction.

Sprinkler Station Jr.:

Plan how far around in each direction you would like the sprinkler to spray.

Sprinkler Station Squared:

Plan which rectangle you would like the sprinkler to spray.

9 x 18 foot rectangle

4 x 15 rectangle



4 x 30 foot rectangle

*** PLAN ONLY AT THIS STEP.** Actually set the sprinkler during installation. The Installation Guide includes instructions for setting the spray pattern.

** IMPORTANT REMINDERS

Plan access to connect your hose.

- Maximum 340 degree angle recommended for Original and Jr. for hose access to avoid getting sprayed when turning on and off the sprinkler and interference from the hose.
- Place the hose connection minimum of 1 foot from a fence or other boundary.



HELPFUL HINTS:

Three (3) Original Sprinkler Stations cover many lawns efficiently.


Use the Sprinkler Station Jr. and Sprinkler Station Squared to cover smaller areas while avoiding spraying driveways and walkways.

Use a splitter and 2 or three hoses at the same time to use more than one sprinkler, or use one hose and plug it into each sprinkler separately.

Use a shutoff timer to turn off the water after the correct amount of time and then roll the hose up at your convenience.


TYPICAL LAYOUTS:

2 ORIGINAL SPRINKLER STATIONS
1 SPRINKLER STATION JR.
2 SPRINKLER STATIONS SQUARED




3 ORIGINAL SPRINKLER STATIONS


2 ORIGINAL SPRINKLER STATIONS
1 SPRINKLER STATION SQUARED



3 ORIGINAL SPRINKLER STATIONS
2 SPRINKLER STATIONS SQUARED




2 ORIGINAL SPRINKLER STATIONS



1 SPRINKLER STATION JR.
2 SPRINKLER STATIONS SQUARED

1 ORIGINAL SPRINKLER STATION
3 SPRINKLER STATIONS SQUARED



2 ORIGINAL SPRINKLER STATIONS